

How to replace the tubes of the CloudCuddle frame

Sequence

- A. Remove the old tube
- B. Set aside the loose parts (sleeves and clip)
- C. Install the new tube. Required: pliers
 1. Attach to left vent.
 2. Slide parts over tube.
 3. Attach to right vent.



A. Steps – remove old tube



1. Slide the sleeve at the end to the left and right.

You will see a cable-tie under it.



2. Use pliers to cut the cable-tie.



3. Remove the cable-ties and remove the tube from the valves.



- B. Slide the parts off the tube and set them aside. Reassemble them in the same order.

C. Steps – install new tube



1. Slide the tubes as far as possible over the valve – up to the raised edge – see arrow (Use soapy water if necessary).



Secure with a cable-tie and cut the ends off, as short as possible



2. Slide the sleeve (1) over the tube and pull it over the cable-tie.



3. Slide the clip + sleeve (3) over the tube and close the clip.



Slide the sleeve (2) over the clip



and open the clip again.



5. Slide the sleeve (4) over the tube



and slide the tube over the right-hand valve.



7. Secure the tie-wrap



and cut off the ends, as short as possible.



8. Slide the sleeve (4) over it.



Done!